


Ascend II Electric Height Adjustable



Ascend II *Electric Height Adjustable*

2-Stage Base (A222)
2 legs / 2 motors
Adjusts 27.2"H to 44.5"H
17.3" range
220 lb. load rating



3-Stage Base (A322)
2 legs / 2 motors
Adjusts 24.5"H to 50"H
25.5" range
250 lb. load rating



3-Stage L-Shape Base (A333)
3 legs / 3 motors
Adjusts 24.5"H to 50"H
25.5" range
325 lb. load rating



2-Way Width-Adjustable Base
Adjusts from 58.4" to 74.5" in 2 directions, supporting 60" to 75" of worksurface area.

Ascend II Electric Height Adjustable




FAST
36mm/s 0-100 lb. load
32mm/s 100+ lb. load


QUALITY
Meets ANSI BIFMA
Meets UL962
5 Year Warranty

QUIET
Sound under 45DB
without load


Bases




A2EB322-xx
3-Stage/2-Leg
CU:3.0 WT:77



A2EB333-xx
3-Stage/3-Leg
CU:3.3 WT:110




A2FEET30-x
Feet for 30"D Tops
(set of 2)



A2EB222-x
2-Stage/2-Leg
CU:3.0 WT:77

Ascend II *Electric Height Adjustable*

BASE MUST BE INITIALIZED BEFORE USE !



Step	Operation	Motion
1	Press and hold ^ & v simultaneously for more than 3 seconds	Legs begin to move down at half speed of normal operation
2	Keep pressing ^ & v	Legs move down to the lowest position and rebound 2-5 mm, then stop
3	Release ^ & v together	Initialization is completed

OTHER FUNCTIONS

Up/down

Memory Positions

Lock Lowest Stroke...table will not go below this point

Lock Highest Stroke...table will not go above this point

Anti-Collision Sensitivity...safety feature can be adjusted to stop faster/slower